

Scope: Comparability of measurements



Revision of the "Guidelines on testing conditions for articles in contact with foodstuffs (with a focus on kitchenware)" 1st edition 2009 to harmonize implementation of Regulation (EU) 2017/625



HOW

EURL-FCM and NRLs have agreed on a set of test condition

(i.e. contact temperature and contact time) for kitchenware articles to ensure the comparability of measurement results reported in the frame of official controls



Deliverables

- √2019 Guideline on "Testing conditions for kitchenware articles in contact with foodstuffs -Part 1: Plastics;
- √2020 Guideline on "Testing conditions for kitchenware articles in contact with foodstuffs -Part 2: Plastics and Metals:
- √2021 Guideline on "Testing conditions for kitchenware articles in contact with foodstuffs -Part 3: Plastics , Metals, Silicone & Rubber;ONGOING





Test conditions plastic, metals, silicone & rubber

- ➤ The test conditions for migration from plastics are based on expert judgement on the "worst case" foreseeable conditions of use by the consumer, not on the use intended by the producer. following principles of sections 2.1.3 and 2.1.4 (SM) and 3.1 (OM) of Annex V of Regulation (EU) No 10/2011.
- ➤ No material specific EU legislation exists for metals and alloys, silicone and rubber in contact with food (except Art. 3 of Regulation (EC) No 1935/2004) → national legislation shall apply. In the absence of national legislation, the test conditions in presented guidelines.
- ➤ Since in most cases consumers would make the same use of a specific utensil, independently of the material it is made of, the test conditions presented in these guidelines are generally based on the test conditions for plastics articles.



Test conditions plastic, metals, silicone & rubber

The test conditions for migration from plastics are based on expert in "worst case" foreseeable conditions of use by the consumer, not of the producer. following principles of sections 2.1.3 and 2.1.4 (SM) a of Regulation (EU) No 10/2011.

Still non-harmonized situation

- ➤ No material specific EU legislation exists for metals and alloys, silicon the rubber in contact with food (except Art. 3 of Regulation (EC) No 1935/2004) → na onal legislation shall apply. In the absence of national legislation, the test conditions in presented guidelines.
- Since in most cases consumers would make the same use of a specific utensil, independently of the material it is made of, the test conditions presented in these guidelines are generally based on the test conditions for plastics articles.



Food simulants plastic, metals, silicone & rubber

- ➤ Plastics: Regulation (EU) No 10/2011
- Metals and alloys, silicone and rubber: follow national legislation and in absence
 - ➤ other guidance may be used, e.g. the practical guideline of the CoE or recommendations and in absence of those
 - food simulants for plastics
 - Metals: if tested with a food simulant for acidic foods (pH \leq 4.5), additional testing in artificial tap water is not required.
- If for any reason the indicated food simulants are not appropriate, testing with **food** should be considered
- NOTE: results in food prevail over the results obtained in food simulant.



Guidance recommendations

This guideline recommends also on:

- > sample preparation e.g. cutting or not
- **test type:** immersion, filling, migration cell or by real use for assembled articles
- > surface-to-volume: The test results need to be recalculated based on real S/V ratio according to Article 17 of Regulation (EU) No 10/2011.
 - This concept is also valid for metals.
 - > The "envelop volume method" developed by the Council of Europe can be used



How to select the test conditions (1):

- 1. At first, select the test conditions recommended by the present guide
- 2. When this guideline assigns several possible test conditions for the same type of article, the most conservative test condition should be used appropriate for the specific article
- 3. If the prescribed test conditions may damage the test specimen to be investigated (e.g. physico-chemical changes) the migration tests shall be carried out under the "worst foreseeable conditions of use" to avoid any physico-chemical changes to occur
- 4. If a **food simulant** causes changes to the test specimen, e.g. swelling, that does not occur with food, this food simulant is not suitable. The migration test should then be performed using food or another equivalent food simulant not causing such changes



How to select the test conditions (2):

- For articles used only under specific conditions (e.g. time, temperature) and/or for specific foods the selected test conditions and food simulants should comply with those specific conditions of use
- 6. If a <u>permanent label</u> is present on the article (e.g. embossed or engraved) defining limiting conditions of use or providing operating instructions, the test conditions should be adapted accordingly BUT if the instructions are <u>ONLY on the packaging</u> (can be discharged) or not present at all the most severe test condition for that type of article needs to be selected.





Structure (1): How does it look like?

Introduction: Defines the scope and explains how to read and use the guideline

Table 1 provides a not exhaustive list of examples of articles clustered in material independent classes and subclasses of kitchen and tableware.


Kitchenware examples					
Main Class	Subclass	Examples			
	FPW/CA1	Aprons, Bibs			
Food Preparation Wear	FPW/CA2	Gloves			
	FPW/CA3	Towels, Wipes, Napkins, Tablecloth, Placemats			
	FPW/CA4	Cheese cloth (dairy product), Plastic mat for cheese draining			
Food Preparation Utensil for Cold/Ambient use (FPU/CA)	FPU/CA1	Utersils use in amilient temperature for short time: Rolling pin, Lattite cutter, Grater, Grater, Deske Zeeter, Vegetable peeler, Apple positer, Ford Caules, Apple courte, Forder, Apple cutter, Biomard press, Chemy prister, Egg sparator, Fin scient, Flour stiffs when chopper, Squeezee, Reamer, Mandolin, Witers, Meet tenderser, Fruit baller, Nutmeg parter, Rest Mondolin, Worter, Meet tenderser, Fruit baller, Nutmeg parter, Rest Desker, Mondolin witer, Mandolin peeler, Austocal objecter, Rastolin maker, Vegetable cutter with			
		container, Hamburger press, Coconut scraper, Empanadilla mould type, Meat grinder, Vegetable brush, Cake measuring tape Cocktail shaker, Coffee measuring spoon			
	FPU/CAH1	Utersits use in ambient or hot temperature for therit time. Baster, Bettle Top Baster, Pathry spatula, Pathry scraper, Pathry housh, Pathry hag, Egg interor, Pathry land, Saled/ornelst-fifthmess shaler, White, Manninde Symper, Brunne, Pathress pathry Long Descard/appetizers rings, Measuring spoon, Measuring cup, Tea net, Ricer, Food mill, Chocolate thermometer, Chocolate forms.			
Food Preparation Utensils	FPU/CAH2	Cutting boards (not for storage)			
for Cold/Ambient or Hot use	FPU/CAH3	Kitchen countertop, Worktop, Bench			
	FPU/CAH4	Colander, Drum sieve, Chinois, Gravy strainer, Cooling rack			
	FPU/CAH5	Bowls			
	FPU/CAH6	Microwave materials (only warming up or defrosting)			
	FPU/CAH7	Puree masher, Potato masher, Tongs-not foreseeable use at temperatures above 100 °C			
	FPU/H1	Articles that could be used during cooking/frying/grilling: Spoon, Ladle, Spatula, Tongs			
Food Preparation Utensils for Hot use	FPU/H2	Cookware , cooking items, microwave cookingware: Steamer basket, lids (sold alone), Spice/fragrance bags, Boil over preventer, Frying pan splatter screens, Fondue forks, bourguignon fork, Cooking rings, Susceptor, microwave cooker			
	FPU/H3	Bakeware and Overware items: Cake pan, Gratin dish, Cookie sheet, Muffin pan, Cooking tray, Oven liners			
	FPU/H4	Roasting bags			
Food Serving Utensils for Cold/Ambient use	FSU/CA1	Bread Bag, Basket (not for storage)			
	FSU/CA2	Decanters, Fitness/bicycle bottles, Baby food pouches			
	FSU/CA3	Dispenser: Candy dispenser, Honey dispenser, Oil dispenser, Sauce dispenser			
Food Serving Utensils for Cold/Ambient or Hot use	FSU/CAH1	Cup, Glasses, Drinkware			
	FSU/CAH2	Open flask, Carafe, Cans, Jugs			
	FSU/CAH3	Bottles without caps			
	FSU/CAH4	Baby bottles			
	FSU/CAH5	Tableware, Plates, Dishware, Serving stand			
	FSU/CAH6	Food trays, Serving board, French fries box, Finger food bags, Snack box, Popcorn box			
	FSU/CAH7	Thermos flask, Isothermic drinking beaker			



Structure (2):

Tables 2, 3 and 4 present the relevant test conditions, for each main class and subclass of kitchen articles made of plastic, metal and silicone & rubber, respectively.

- foreseeable use of the article
- Sample preparation
- Test type
- Food simulant
- · Specific migration test conditions
- Surface-to-volume
- · Overall migration test conditions





Structure (2)

Table 5 describes the rationale behind the selection of test time and temperature for specific migration

time	temperature	Sub-class	Rational/justification
0.5 h	20 °C	FSI/CA1	According to Regulation 10/2011, for uteralls in contact with food for a short time [< 0.5 h] at cold temperature (refrigerated), these test conditions apply: 20 °C for 0.5 h.
0.5 h	40 °C	FPW/CA1-3 FPU/CA1 FSI/CA2	According to Regulation 10/2011: - for utenzils in contact with flood for a short time (5 0.5 h) at ambient temperature; or - for givens, learnests and stabilisedists, used for 5.2 h at ambient temperature, having a short contact time (5 0.5 h) with the same portion of food; these pact conditions capels (0.7 for 0.5 h).
0.5 h	70 °C	FPU/CAH1 FSI/CAH1 KSA/CAH3	According to Regulation 10/2011, for utensils in contact with hot food (5.70 °C) for a short time (5.0.5 h) these test conditions apply: 70 °C for 0.5 h.
1.6	40 °C	FSU/CAH4	Foods may be in contact with these articles for short periods of time at temperatures up to 40
2 h	70 °C	FPU/CAH2-4 FPU/CAH7 FSU/CAH3-6 FSU/CAH1-2	Accorging to Regulation 10/2011, for uternills in contact with food for short periods of time at temperatures between 70 and 100 $^{\circ}$ C (cf. "hot fill"), these test conditions apply: 2 hours at 70 $^{\circ}$ C.
2 h at 70 °C followed by		FPU/CAHS FSU/CAH1-4	Foods may be in contact with these utensils for short periods of time at temperatures betwee 70 and 100°C. The food/beverage could then be stored in the same "container" for a day at
	24h at 40 °C	FSI/CAH2 FC/CAH1	room temperature or colder. According to Regulation 10/2011 these test conditions apply: 2 h at 70 °C (cf. hot fill) followed by 24 h at 40 °C.
24 h	40 °C	FSU/CA1-2 FSU/CAH1-2 FSU/CA2	According to Regulation 10/2011, for utensits in contact with food (drinkware, tableware and cullery used for cold and RT purpose ORLY) for up to 2 day at ambient temperature, these test conditions apply 2.6 h and 40 °C.
24 h	100 °C	FSU/CAH7	Fill with food simulant @ 100 °C and keep the container closed for 24 h - as real use for
10 d	5*0	FC/CAH2	According to Regulation 10/3011, - for articles in contact with any food at frozen and refrigerated conditions.
20 d	20 °C	FSI/CA1	According to Regulation 10/2011, - for utenals in contact with food for more than 30 days at frozen temperature.
10 d	40 °C	FPU/CAHS FPU/CAHB FSU/CAHS-4 FSU/CA3 FSI/CAH2	According to Regulation 10/2011. - for uteralist in contact with flood for more than 30 days at raffigurated or floosen temperature including here fill conditions another heating up to 70 % or 1 x 100 % for maximum t = 110/2**[[7]]/[7]]/[7]]/[7]]/[7]. Invitables in contact with flood for up to 30 days at morn temperature.



Acknowledgment: TF members, NRL, OCL

Task Force on Kitchenware consisting of representatives of:

- National Reference Laboratories of Belgium, Germany, Greece, Italy and Spain,
- the European Directorate for the Quality of Medicines & Health Care of the Council of Europe and
- the Federation of European manufacturers of Cookware and cutlery (FEC)
- Commission (DG SANTE and JRC)

The tables were reviewed by the National Reference Laboratories and official control laboratories dealing with food contact materials, in accordance with Article 94 (2)(a) of Regulation (EU) 2017/625

